

Repair instruction

Description: C2 C3 C4 Float arm

Part number: 21322 Float arm

Look for Service Centers, Point of Sale addresses and other information on: www.thetford-europe.com



Version: V2

Date: 17/07/2006

Tools required: 

A

Remove the sliding cover.



Float arm is assembled on the opposite side of the blade opener.

B


Open the blade.



The Magnet has to point to the outside of the waste tank.


C

Remove the float retainer (if this is still in the waste tank) by placing the small flat screwdriver between the rib and the float retainer and lift it up.



D

Place the new float arm.



E

Press on the float-retainer.

