



## Repair instruction

**Description:** C2 C3 C4 Vent seal



**Part number:** 20339

Look for Service Centers, Point of Sale addresses and other information on: [www.thetford-europe.com](http://www.thetford-europe.com)

<b>Version:</b>	V1
<b>Date:</b>	15/06/2006
<b>Tools required:</b>	 


**A**

Open the blade, and depress the vent seal (1) around outer edge of seal (1a).



**B**

Take the vent seal out (2).



**C**

Bring new vent seal on its place as shown. Thinner flange has to be on the float which is inside the waste tank.



Thinner flange



Float

D

Depress the vent seal through the hole, from the outside. **Note:** Make sure that the vent seal is lying in the middle of the hole, when looking from the top.

Go with your hand in the waste tank.

E

press against the float (vent seal will be pressed into its place).

